

Barudan

BEDS/DY/DX

Quick Reference Guide

Copyright 7/03
BARUDAN CO., LTD.
906 Josuiji, Ichinomiya-city
Aichi-pref., Japan

Function Keys



Speed, opens the speed control menu, to increase/decrease sewing speed.



Needle, opens the menu to select the needle that will start sewing.



Trim, executes a manual thread trim on all active sewing heads.



Manual, opens the menu to execute specific machine functions, such as Clamp, Trim, etc.



Network, connects machines from a central computer: Upload and download patterns as well as control production.



Read, transfers patterns from floppy disk, or peripheral devices to memory; accesses floppy disk utilities.



Memory, opens the Pattern List and Memory menu, access to patterns in memory.



Teach, locates and changes existing function codes in a pattern.



Float, moves the machine through the pattern without sewing.




Drive, places the machine in Drive mode ready to sew.




Page, toggles between basic and drive mode screens. It may be pressed at any time.

Powering On



Move **Power switch** to the **On** position, press **green Power On** button. The machine makes one long beep indicating it has been powered on. Press **Execute** icon, machine will seek origin, and basic screen displays.


Viewing Pattern from a Disk



Insert floppy disk, press **READ** key, select pattern using jog keys, press **Pat. Char.**, press **Draw** to view the pattern on the screen. Press **Pat. Char.** to exit.

NOTE: The disk icon must display on the screen. If this is not the current icon press the A key until it displays.


Loading a Pattern from disk



Insert floppy disk, press the **Read** key, select pattern using jog keys, press **Execute**, pattern will be stored in memory.


NOTE: The disk icon must display on the screen. If this is not the current icon press the A key until it displays.

Loading Pattern from a Compact Flash Card



Insert a compact flash card, press the **Memory** key, press **Next**, press **CF Memory**, use the jog keys to move through the folders, press **E** to display the contents.


Drawing Pattern on Screen



Press **Memory** key, select pattern using the jog keys, press **Draw** to view the pattern on the screen; press Program to see any program changes done to the pattern.


NOTE: If program changes have been applied to the pattern, they will be highlighted.

Changing the Colors using F-List




Press **Memory** key, select pattern using the jog keys, press **Pat. Char.**, select **F-List**, use **jog** keys to choose function, change color code using the **plus and minus** keys, press **Memory** key to exit and accept changes.

Rotating the Pattern 180




Press **Memory** key, select pattern using the **jog keys**, select **Program** key, use jog keys to access Rotate, #3, from the list of parameters use **plus and minus** keys to change Rotate setting; press **Memory** key to exit and save changes.

Selecting the needle to begin sewing




Press **Needle** key, select **Toward first needle**, **Toward last Needle** or **Direct Needle**. Use the **N-** and **N+** icons to select the correct needle, press **Execute** key.

Sewing the pattern




Press **Memory key**, select pattern using **jog keys**, press **Memory key** to exit. Press and hold the **Drive key** until machine beeps. Select **Perimeter trace** to verify pattern is correctly positioned within the frame and on the garment. **Start machine to begin sewing.**

Deleting a Pattern from Memory



Press **Memory** key, use **jog keys** to select pattern to delete, press **Next** key, press **Delete** key, press **Yes** key to delete. The pattern will be deleted from memory.

Powering Off



Switch power source to the **off** position.

Note: Press and hold the Drive key to exit the Drive mode, before turning the machine off.

